



iPod Touch 5th Generation Front Camera Replacement

prerequisite only

Written By: Andrew Optimus Goldberg



INTRODUCTION



prerequisite only



TOOLS:

- [Spudger](#) (1)
-

Step 1 — Front Camera



- Use the flat end of a spudger to flip the front-facing camera out of its socket in the display assembly.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-19 11:58:11 PM.